

OF TIMBER QUALITY PRODUCTS

HOW TO MEASURE ARCHED ARCHITRAVES


Store: _____

Phone No: (0____) _____

Contact: _____

Fax No. (0____) _____

NOTE: If the arch is a true half of the circle, the vertical measurement will be half of the horizontal one


STEP 1: Measure **H** in mm: horizontal internal window width.

STEP 2: Measure **V** in mm: Vertical internal window height taken from the **centre** of the horizontal line between points (a) and (b) as shown in diagram above

STEP 3: Add set back for architrave from inside edge of window frame (Quirk).

Standard Quirk = 3 to 5 mm. See diagram above

STEP 4: To match your architrave profile/size of material/type of timber or MDF, please provide 100 mm long sample. It can be mailed.

STEP 5: Supply code of profile if available.

STEP 6: If your window is not true radius, please supply template.

NOTE: We will supply the architrave longer so you can cut to size

EXAMPLE:

How many windows the same

Generally 3-5 mm

CODE: _____ **Quantity:** 1 **Horizontal:** 1200 mm **Vertical:** 600 mm **+ Quirk:** 3 mm

MATERIAL: Size: 90 x 42 mm ☒ **MDF** ☐ **LOSP T / PINE** or **OTHER** _____

TO ORDER, FILL IN BELOW

CODE: _____ **Quantity:** _____ **Horizontal:** _____ mm **Vertical:** _____ mm **+ Quirk:** _____ mm

MATERIAL: Size: _____ x _____ mm ☐ **MDF** ☐ **LOSP T / PINE** or **OTHER** _____

Please note that it is your responsibility to check all sizes are correct.